Konica 1312

SERVICE HANDBOOK

May. 1999

Ver. 2.0

KONICA CORPORATION

TECHNOLOGY SUPPORT CENTER

TOKYO JAPAN

Powered by

Aleck Kholopov

Slash, Ltd

☎ 095 201 48 20

http://www.slash.ru

slash@slash.ru

Powered by
Aleck Kholopov
Slash, Ltd
☎ 095 201 48 20
http://www.slash.ru
slash@slash.ru

Chapter 1 Specifications

1-1. Outline 1-1
1-2. Guaranteed working conditions 1-1
1-3. General specifications 1-2
1-4. Copy specifications 1-2
1-5. Consumable parts specifications 1-3
1-6. Option specifications 1-3
1-7. Factory installed options specifications 1-3

Chapter 2 Installation

2-1. 1312 INSTALLATION PROCEDURE 2-1
2-1-1. Removing protective materials 2-2
2-1-2. Preparing for the drum unit and the developing unit 2-3
2-1-3. Loading the toner cartridge 2-5
2-1-4. Installing the paper exit tray 2-5
2-1-5. Loading copying paper 2-6
2-1-6. Turning on the power and initializing the developing unit and setting the paper size 2-7
2-2. DEVELOPING UNIT INSTALLATION PROCEDURE 2-9
2-2-1. Replace the developing unit 2-9
2-2-2. Loading the toner cartridge 2-10
2-2-3. Initializing the developing unit 2-10
2-3. DRUM UNIT INSTALLATION PROCEDURE 2-11
2-3-1. Replacing the drum unit 2-11
2-3-2. Initializing the drum unit 2-13
△1 2-3-3. Cleaning the pressure(rubber)roller .. 2-13
2-4. TONER CARTRIDGE INSTALLATION PROCEDURE 2-14
2-4-1. Loading the toner cartridge 2-14
2-4-2. Replacing the cleaning pad 2-15
2-5. CASSETTE FEEDER INSTALLATION PROCEDURE 2-16
2-5-1. Installing the cassette feeder 2-16
2-5-2. Setting the paper size 2-17
2-6. REPLACEMENT OF THE DEVELOPER . 2-18
2-6-1. Replacement of the developer 2-18
△1 2-7. PRESSURE(RUBBER)ROLLER CLEANING PROCEDURE 2-19
△1 2-7-1. Cleaning the pressure(rubber)roller (Periodic cleaning) 2-19
△1 2-7-2. Cleaning the pressure(rubber)roller (Additional cleaning) 2-21

Chapter 3 Operating Instructions

3-7. Machine configuration and function 3-1
3-1-1. Main Body 3-1
3-1-2. Control Panel 3-3
3-2. Copying operations 3-5
3-2-1. How to Make a Basic Copy 3-5
3-2-2. Copy Using the Manual Feed Bypass Tray 3-7
3-2-3. RE(Preset Ratio)Mode 3-7
3-2-4. Zoom Mode 3-8
3-2-5. Useful Functions 3-9
3-2-6. Setting Procedure 3-10
3-3. Troubleshooting 3-13
3-3-1. Copy Quality-Related Troubles 3-13
3-3-2. Error Codes and Remedies 3-14
3-4. Copier management 3-18
3-4-1. Periodic Maintenance 3-18
3-4-2. Daily Maintenance 3-27
3-4-3. Copy Materials 3-29

Chapter 4 Adjustment

4-1. Toner density 4-1
4-2. Fusing temperature 4-1
4-3. Exposure voltage 4-2
4-4. Image position 4-2
4-4-1. Center position 4-2
4-4-2. Leading edge position 4-3
4-4-3. Image skew 4-3
4-5. Magnification adjustment 4-3
4-5-1. Feeding direction (Vertical magnification) 4-3
4-5-2. Crosswise direction (Horizontal magnification) 4-4
4-6. Optical section adjustment 4-4
4-6-1. Light distribution 4-4
4-6-2. Scanner reference position 4-5
4-6-3. Lens reference position 4-5
4-6-4. Diagonal distortion 4-5
4-6-5. Image distortion 4-5
4-6-6. Focus 4-5
4-6-7. Image center position 4-6
4-6-8. Focus (Horizontal blurring) 4-6
4-6-9. Horizontal magnification 4-6
4-7. Leading and trailing edges erase width 4-6

Chapter 5 Disassembly

5-1. Cover 5-1
5-1-1. Platen cover 5-1
5-1-2. Left cover 5-1
5-1-3. Right cover 5-1
5-1-4. Upper rear cover 5-1
5-1-5. Lower rear cover 5-1
5-1-6. Front cover 5-1
5-2. Platen glass 5-2
5-3. Operation panel 5-2
5-4. Paper feed unit 5-2
△1 5-4-1. Paper feed (segment) roller(Main unit) .. 5-2
△1 5-4-1'. Paper feed (segment) roller (Optional cassette feeder) 5-2-1

Powered by
Aleck Kholopov
Slash, Ltd
☎ 095 201 48 20
http://www.slash.ru
slash@slash.ru

5-4-2. Slip roller 5-3
5-5. Conveyance and transfer unit 5-3
5-5-1. Transfer roller 5-3
5-5-2. Upper regist roller 5-3
5-5-3. Lower regist roller 5-3
5-6. Fixing unit 5-4
5-6-1. Fixing upper cover 5-4
5-6-2. Thermistor and thermostat 5-4
5-6-3. Heater lamp 5-4
5-6-4. Separation claws 5-4
5-6-5. Heat roller 5-5
5-6-6. Pressure (rubber) roller 5-5
5-7. Optical section 5-5
5-7-1. Lens cover 5-5
5-7-2. No. 6 mirror unit 5-5
5-7-3. Exposure lamp 5-5
5-7-4. Temperature fuse 5-5
5-7-5. Scanner wire 5-6
5-8. SDH unit 5-6
5-8-1. S1sensor 5-6
5-8-2. S2 sensor 5-6
5-8-3. Paper feed clutch, paper feed roller 5-7
5-8-4. Separation roller 5-7
5-8-5. Gear frame 5-7
5-8-6. Lower conveyance roller 5-7
5-8-7. Lower turn roller 5-7
5-8-8. Upper turn roller 5-7
5-8-9. Paper exit roller 5-7
5-8-10. Upper conveyance roller 5-8
5-9. PCB 5-8
5-9-1. Operation PCB 5-8
5-9-2. Main PCB 5-8
5-9-3. High voltage PCB 5-9
5-9-4. Power PCB 5-9
5-10. Replacement of the Ozone filter 5-10

Chapter 6 Mechanism

6-1. Copy process 6-1
6-2. Front cross-section (Main mechanism parts layout drawing) 6-3
6-3. Drive conveyance system diagram 6-4

Chapter 7 Electricity

7-1. Main control circuits 7-1
7-1-1. Toner density control 7-1
7-1-2. Fusing temperature control 7-2
7-1-3. JAM detection 7-3
7-1-4. Safety circuit 7-4
7-2. Timing chart 7-5
7-2-1. A4, TWO COPIES, CASSETTE PAPER FEED (UPPER) 7-5
7-2-2. A4, TWO COPIES, CASSETTE PAPER FEED (LOWER) 7-5
7-3. Connector list 7-6
7-3-1. Main CB (UNIT MAIN) 7-6
7-3-2. High voltage unit (UNIT HV) 7-9
7-3-3. Power supply board (UNIT PSU) 7-12
7-4. IC list 7-13
7-5. Test points and VR list 7-14
7-6. Electrical parts layout drawing 7-14
7-6-1. PCB, lamp (heater), fuse (rating) 7-14
7-6-2. Clutches (solenoid) and motors 7-15
7-6-3. Sensors and switches 7-15

Chapter 8 Service Functions

8-1. Error codes 8-1
8-2. User setting mode 8-4
8-2-1. Setting procedure 8-4
8-2-2. Setting item list 8-4
8-3. Service mode 8-6
8-3-1. Entering the service mode 8-6
8-3-2. 25 mode 8-7
8-3-3. 36 mode 8-9
8-3-4. 47 mode 8-11
8-4. Backup data 8-13
8-5. Automatic paper size detection 8-13
8-6. General operation mode 8-14

Chapter 9 Troubleshooting

9-1. Defective image and diagnosis flow 9-1
9-1-1. Both sides and trailing edge is black when making a reduced copy 9-1
9-1-2. Background fogging (White background fogging) 9-2
9-1-3. Black lines 9-3
9-1-4. Center deviation 9-4
9-1-5. Smearing 9-5
9-1-6. Light copy 9-6
9-1-7. Dark copy 9-7
9-1-8. Partial skipping of transfer 9-8
9-1-9. Copy is black 9-9
9-1-10. No image 9-10
9-1-11. Distorted image 9-11
9-1-12. White band 9-12
9-1-13. Black band 9-13
9-1-14. Density balance deviation 9-14
9-1-15. Leading position deviation 9-15
9-1-16. Contamination 9-16
9-1-17. Jittering 9-17
9-1-18. White dots on black matte section 9-18
9-1-19. Extremely light copy 9-19
9-2. Operation defects 9-20
9-2-1. Power does not turn ON 9-20
9-2-2. Copying operation is not possible 9-20
9-2-3. Paper feed or conveyance defect 9-20
9-2-4. Abnormal noise 9-21
9-2-5. Special symptoms 9-22
9-2-6. Malfunction 9-22

Chapter 10 Maintenance

10-1. Replacement cycle 10-1
10-2. Maintenance 10-2

Chapter 11 Wiring/Circuit Diagrams

1312/1312F Wiring Diagram for 120V 11-1
1312/1312F Wiring Diagram for 220V to 240V 11-2
UNIT PSU (1/3) for 120V 11-3
UNIT PSU MAIN REGULATOR (2/3) for 120V 11-4
UNIT PSU LAMP REGULATOR (3/3) for 120V 11-5
UNIT PSU (1/3) for 220V to 240V 11-6
UNIT PSU MAIN REGULATOR (2/3) for 220V to 240V 11-7
UNIT PSU LAMP REGULATOR (3/3) for 220V to 240V 11-8
UNIT FUSE 11-9
UNIT MAIN (1/9) 11-10
UNIT MAIN CONTROL (2/9) 11-11
UNIT MAIN OPERATION I/F (3/9) 11-12
UNIT MAIN FUSER I/F (4/9) 11-13
UNIT MAIN POWER SUPPLY I/F (5/9) 11-14
UNIT MAIN CLUTCH I/F (6/9) 11-15
UNIT MAIN LOWER CASSETTE I/F (7/9) ... 11-16
UNIT MAIN STEPPING MOTOR I/F (8/9) 11-17
UNIT MAIN EXTIO I/F (9/9) 11-18
UNIT OPERATION (1/2) 11-19
UNIT OPERATION (2/2) 11-20
UNIT HV (1/4) 11-21
UNIT HV HIGH VOLTAGE (2/4) 11-22
UNIT HV STEPPING MOTOR (3/4) 11-23
UNIT HV TONER MOTOR (4/4) 11-24
UNIT ERASE 11-25
UNIT SIDE ERASE 11-26
PF-105/105H Wiring Diagram 11-27
UNIT CASSETTE FEEDER 11-28