CONTENTS

SAFETY AND IMPORTANT WARNING ITEMS .....
Refer to the 7020 service handbook on page C-1

1. ADJUSTMENT

HOW TO USE THE ADJUSTMENT SECTION 1-1
[1] Construction 1-1
ADJUSTMENTS WHEN REPLACING PARTS 1-1
LIST OF ADJUSTMENT ITEMS 1-2
MODE CHANGE MENU 1-3
[1] Setting method 1-3
CHECK OF COUNT VALUE WITH P FUNCTION 1-4
[1] How to use P function 1-4
25 MODE 1-5
[1] Setting method 1-6
[2] Setting software DIP SW 1-6
[3] PM count setting 1-17
[4] Data collection 1-18
[5] Copy count for each part to be replaced .. 1-23
[6] Password setting 1-27
[7] Setting phone number of the service center 1-29
[8] Setting the serial number 1-29
[9] Displaying the ROM version 1-30
[10] Outline 1-31
[11] Specifications 1-31
[12] KRDS setting 1-31
[13] KRDS set up 1-32
[14] Call setting menu mode (Arbitrary) 1-43
[15] KRDS host call 1-46
[16] FAX KRDS auto on function 1-47
[17] A point to notice for operation 1-47
[18] ASCII code table 1-48
[19] Error code table 1-49
[20] ISW setting 1-49
[21] Root counter display 1-49
36 MODE 1-50
[1] Setting method 1-54
[2] High voltage adjustment 1-54
[3] Timing adjustment 1-55
[4] Running test mode 1-65
[5] Test pattern output 1-66
[6] Test pattern density adjustment 1-70
[7] Image quality adjustment 1-70
[8] List print 1-71
[9] Counter clear 1-72
[10] Adjustment of RADF 1-73
[11] FNS adjustment 1-77
47 MODE 1-90
[1] 47 mode setting method 1-90
[2] Initial setting in the field 1-91
[3] RADF original size detection adjustment ... 1-92
[4] Electronic RDH memory check 1-92
[5] Input check list 1-93
[6] Output check list 1-95
OTHER ADJUSTMENTS 1-100
[1] RADF mounting position adjustment .. 1-100
[2] RADF distortion adjustment 1-100

[3] RADF skew adjustment 1-101
[4] DB-409 paper-incline adjustment 1-101
[5] DB-409 tray tilt adjustment 1-102

ISW

ISW 2-1
[1] Description of the ISW 2-1
[2] Operating method 2-1

SERVICE

SERVICE SCHEDULE 3-1
[1] Service schedule 3-1
[2] Maintenance items 3-2
[3] Periodic check items (main body) 3-5
[4] Periodic check items (options) 3-7
[5] List of actual durable counters for replacement parts 3-8
COPY MATERIALS 3-9
[1] PM parts kit (100,000 copies/kit) 3-9
[2] Consumables (Single unit supply) 3-9
SERVICE MATERIALS LIST 3-10
[1] Maintenance kit composition 3-10
SPECIAL TOOLS LIST 3-11

DIAGRAMS

7020 ELECTRICAL PARTS LAYOUT DRAWING .. 4-1
[1] Switches and sensors 4-1
[2] Loads 4-4
[3] PCBs and others 4-7
DF-314 ELECTRICAL PARTS LAYOUT DRAWING ... 4-9
FS-107 ELECTRICAL PARTS LAYOUT DRAWING .. 4-10
DB-209 ELECTRICAL PARTS LAYOUT DRAWING .. 4-12
DB-409 ELECTRICAL PARTS LAYOUT DRAWING .. 4-14
7020 CONNECTOR LAYOUT DRAWING 4-15
DF-314 CONNECTOR LAYOUT DRAWING 4-22
FS-107 CONNECTOR LAYOUT DRAWING 4-23
DB-209 CONNECTOR LAYOUT DRAWING 4-25
DB-409 CONNECTOR LAYOUT DRAWING 4-26
LIST OF JAM CODES 4-27
LIST OF WARNING (ERROR) CODES 4-30
7020 TIME CHART (A4, LIFE SIZE, 2 COPIES, FEED FROM TRAY 1) 4-42
7020ADU TIME CHART (A4, LIFE SIZE, 3 COPIES, FEED FROM TRAY 1) 4-43
DF-314 TIME CHART (A4, SINGLE SIDE ORIGINAL, 3 SHEETS) 4-44
DF-314 TIME CHART (A4, DOUBLE SIDE ORIGINALS, 2 SHEETS) 4-45
FS-107 TIME CHART (A4, SORT MODE, 2 SHEETS/SET, 2 SETS) 4-46
FS-107 TIME CHART (A4, STAPLE MODE, 2 SHEETS, 1 POSITION) 4-47
DB-209/DB409 TIME CHART (A4, LIFE SIZE, 3 COPIES, FEED FROM TRAY 1) 4-48