CONTENTS

1. SERVICE INSTRUCTION D-1
   1-1. PARTS WHICH MUST NOT BE TOUCHED D-1
      (1) Screws D-1
      (2) Variable Resistors on Boards D-1
      (3) Other Screws D-1
   1-2. READING THE TEXT D-1
   1-3. IDENTIFICATION OF FUSES D-2
   1-4. PRECAUTIONS FOR HANDLING THE LASER EQUIPMENT D-2
2. DISASSEMBLY/REASSEMBLY D-3
   2-1. DOORS, COVERS, AND EXTERIOR PARTS: IDENTIFICATION AND REMOVAL PROCEDURES D-3
   2-2. REMOVAL OF PWBs D-5
   2-3. MAINTENANCE SCHEDULE D-7
   2-4. BELT INSTALLATIONS D-8
   2-5. REMOVAL OF UNITS D-9
      (1) Removal of the Manual Bypass Unit D-10
      (2) Removal of the Paper Take-Up Unit D-11
      (3) Removal of the Imaging Unit D-12
      (4) Removal of the PH Unit D-13
      (5) Removal of the Transport Unit D-14
      (6) Removal of the Fusing Unit D-15
      (7) Removal of the Power Supply Unit D-16
   2-6. PAPER TAKE-UP SECTION D-17
      (1) Disassembly of the Manual Bypass Unit
      Replacement of the Manual Bypass Separator Roll Assy D-17
      (2) Disassembly of the Paper Take-Up Roll D-19
   2-7. IR SECTION D-20
      (1) Cleaning of the 1st to 3rd Mirrors, Slide Rails, Lens and Cooling Fan Filter D-20
      (2) Disassembly of the IR Section D-20
      (3) Removal of the Exposure Lamp and Inverter D-23
      (4) Removal of the Drive Cable D-24
      (5) Winding of the Drive Cable D-24
   2-8. IMAGING UNIT SECTION D-25
      (1) Cleaning of the PC Drum Paper Separator Fingers and Ds Positioning Collars
      Replacement of the PC Drum and Toner Scattering Prevention Plate D-25
      (2) Replacement of the Cleaning Blade D-26
      (3) Cleaning of the Pre-Image Transfer Upper Guide Plate, Magnet Roller Lower Filter and Paper Dust Remover
      Replacement of the Toner Antispill Mylar D-26
      (4) Cleaning of the Main Erase Lamp D-27
      (5) Cleaning and Replacement of the PC Drum Charge Corona Assy D-28