

2. Move the Switch Actuating Plate back and forth to meet the requirements below.

Requirements

- When the Front Door is closed, the Magnetic Catches on both sides are in secure contact.
- When the Front Door is closed, the Interlock Switch indicator on the Control Panel goes out.

3-4. ELECTRICAL/IMAGE ADJUSTMENT

Method of inputting mode

- Tech. Rep. Mode
  Meter Count key → Stop key → 0 → 0 → Stop key → 0 → 1
- Adjust Mode
  Tech. Rep. Mode → Stop key → Start key → Keypad → Start key
  (E.g.: A4 mode if "4" of Keypad is entered)
- Function Mode
  Tech. Rep. Mode → 1 → Start key → Keypad → Start key
  (E.g.: F8 mode if "8" of Keypad is entered)

(1) Adjustment of the ATDC Sensor

Adjustment Procedure

1. Call F8 of the function mode (ATDC level adjustment) to the screen.

F8 ATDC SENSOR
XXX

2. Press the Start key to let the copier make the ATDC Sensor adjustment automatically. (It takes about 4 to 5 min. for the copier to complete the adjustment procedure.) Enter the adjustment value on the label "I/U Assy".
3. After the adjustment has been made, press the Panel Reset key twice (or turn OFF the Power Switch) to return the copier back to the normal mode.

NOTE

Make the ATDC Sensor adjustment whenever fresh starter has been loaded.
If data has been cleared by Memory Clear, use Adjust Mode A8 [ATDC Sensor (Manual)] to re-input the data.
