CONTENTS

1. CONTROL PANEL KEYS AND INDICATORS S-1
2. FUNCTIONS OF SWITCHES AND OTHER PARTS ON PWBs S-3
   2-1. PWB Location S-3
   2-2. Master Board PWB-A S-3
3. USER'S CHOICE MODE S-5
   3-1. Functions Available from the User's Choice Mode S-5
   3-2. User's Choice Mode Setting Procedure S-5
   3-3. User Mode Setting Details S-6
4. TECH. REP. MODE S-9
   4-1. Tech. Rep. Mode Function Tree S-9
   4-2. Tech. Rep. Mode Function Setting Procedure S-10
   4-3. Settings in the Tech. Rep. Mode S-11
      (1) Function (test) S-11
      (2) Tech. Rep. Choice S-12
      (3) Change Fixed Zoom S-15
      (4) PM Counters S-15
      (5) Paper Counters S-16
      (6) Jam Counters S-16
      (7) Trouble Code Counters S-17
      (8) Consumables Counters S-18
      (9) Input Paper Size S-18
      (10) Display Test S-18
      (11) ROM Version S-19
      (12) Application Counters S-19
      (13) Marketing Area S-19
      (14) Service Call No. S-19
5. ADJUST MODE S-20
   5-1. Functions Available in the Adjust Mode S-20
   5-2. Entering the Adjust Mode S-20
   5-3. Settings in the Adjust Mode S-21
6. SECURITY MODE S-23
   6-1. Functions Available in the Security Mode S-23
   6-2. Entering the Security Mode S-23
   6-3. Settings in the Security Mode S-24