<Clearing Procedures>

- Initialize Points PJ29

1. Turn OFF the Power Switch.
2. With PJ29 closed, turn ON the Power Switch.
3. In approx. 5 sec., open PJ29.
4. Check that the message "completed Push #key." is displayed on the Message Display and then press the # key.

- Memory Clear Test Point TP1

1. Turn OFF the Power Switch.
2. With the circuit across TP1 and TP3 closed, turn ON the Power Switch.
3. In approx. 5 sec., open the circuit across TP1 and 3.
4. Check that the message "completed Push #key." is displayed on the Message Display and then press the # key.

NOTES

- *If an erratic operation or display occurs, perform the clearing procedures in the order of PJ29 and TP1.*
- *When memory clear has been performed, make the necessary settings again.*

<List of Data Cleared by Switches and Points>

Clearing Means / Data Cleared	Front Door Open/Close	Trouble Reset Switch S1	Initialize Points PJ29	Memory Clear Test Point TP1
Misfeed display	❍	❍	❍	❍
Malfunction display (excluding Exposure Lamp and fusing malfunctions)	❍	❍	❍	❍
Malfunction display (all including Exposure Lamp and fusing malfunctions)	—	❍	❍	❍
Erratic operation/display	—	—	❍	❍
User mode	—	—	—	❍
Service mode	—	—	—	❍
F8 adjustment value	—	—	—	❍
Adjust mode	—	—	—	❍
Security mode	—	—	—	❍

❍: Cleared —: Not cleared