3 USER'S CHOICE MODE

- This mode is used to make various settings according to the user's needs.

3-1. Functions Available from the User's Choice Mode

No.	Function
0	MIXED ORIG. SIZE
4	ORIGINAL THICKNESS
7	DISABLE SLEEP MODE
10	PAPER PRIORITY
12	COPY MODE PRIORITY
14	EXPO. MODE PRIORITY
16	EXPO. LEVEL (AUTO)

No.	Function
17	EXPO. LEVEL (MANUAL)
20	AUTO PANEL RESET
21	ENERGY SAVER MODE
23	REMOVE KEY COUNTER
28	SLEEP MODE
30	SELECT LANGUAGE
40	ZOOM MEMORY

3-2. User's Choice Mode Setting Procedure

<Setting Procedure>

1. With the Message Display indicating that a copy cycle can be initiated, hold down the Panel Reset key for about 5 seconds or more. Then, the following message appears on the display:

USER'S CHOICE SELECT 10 KEY INPUT:

2. From the Keypad, enter the number assigned to the desired function to be set.
3. Press the Start key. Then, the current setting for that particular function appears.
4. Enter the new setting from the Keypad.
5. Press the Start key to validate the entry of the new setting.

NOTE

If an illegal value is entered, the copier rejects it similarly to when the Clear key is pressed.

<Leaving the User's Choice Mode>

- Press the Panel Reset key.