<table>
<tr><th>Function No.</th><th>Setting (The default is Highlighted).</th></tr>
<tr><td>14</td><td>
<EXPO. MODE PRIORITY>
Select the priority exposure mode that is automatically selected in the initial mode.
<table>
<tr><td>Data</td><td>0</td><td>1</td></tr>
<tr><td>Description</td><td>Auto Exposure</td><td>Manual Exposure</td></tr>
</table>
</td></tr>
<tr><td>16</td><td>
<EXPO. LEVEL (AUTO)>
Select the priority exposure level that is automatically selected in the Auto Exposure mode.
<table>
<tr><td>Data</td><td>0</td><td>1</td><td>2</td></tr>
<tr><td>Description</td><td>Lighter</td><td>Normal</td><td>Darker</td></tr>
</table>
</td></tr>
<tr><td>17</td><td>
<EXPO. LEVEL (MANUAL)>
Select the priority exposure level that is automatically selected in the Manual Exposure mode.
<table>
<tr><td>Data</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr>
<tr><td>Description</td><td>EXP. 1</td><td>EXP. 2</td><td>EXP. 3</td><td>EXP. 4</td><td>EXP. 5</td></tr>
</table>
</td></tr>
<tr><td>20</td><td>
<AUTO PANEL RESET>
Select the time to reset the control panel, or disable the panel reset function.
<table>
<tr><td>Data</td><td>0</td><td>1</td><td>2</td></tr>
<tr><td>Description</td><td>Disabled</td><td>30 sec.</td><td>1 min.</td></tr>
</table>
</td></tr>
<tr><td>21</td><td>
<ENERGY SAVER MODE>
Select the time to allow the copier to enter the Energy Saver mode.
<table>
<tr><td>Data</td><td>1 ..... 15 ..... 240</td></tr>
<tr><td>Description</td><td>The data value is the time in min.</td></tr>
</table>
</td></tr>
<tr><td>23</td><td>
<REMOVE KEY COUNTER>
Select whether to activate the panel reset function when the Plug-In Counter is pulled out.
<table>
<tr><td>Data</td><td>0</td><td>1</td></tr>
<tr><td>Description</td><td>Panel reset is not activated</td><td>Activated</td></tr>
</table>
</td></tr>
</table>