4-3. Settings in the Tech. Rep. Mode

(1) Function (test)

- This function allows the Tech. Rep. to perform various functional tests and adjustments.

<Setting Procedure>

1. Enter the number assigned to the desired test from the Keypad and press the Start key.
2. When the Start key is pressed, it starts the test.
3. Press the Stop key to stop the test.

<Leaving the Function>

- Press the Panel Reset key.

Tech. Rep. Mode ▶ Function

<table>
<tr><th>Function No.</th><th>Description</th></tr>
<tr><td>F1</td><td><PAPER PATH>
A paper passage test is carried out after the copier has complete warming up.

NOTE
The test is started with the paper source selected before F1 was invoked.</td></tr>
<tr><td>F2</td><td><DRUM/TRANS CORONA>
Do not use this test as it is only for factory adjustment.</td></tr>
<tr><td>F4</td><td><SEPARATOR CORONA>
Do not use this test as it is only for factory adjustment.</td></tr>
<tr><td>F7</td><td><ORIGINAL SENSOR>
This test automatically adjusts the Original Size Detecting Sensors.

NOTE
For details, see DIS/REASSEMBLY, ADJUSTMENT.</td></tr>
<tr><td>F8</td><td><ATDC SENSOR>
This test automatically adjusts the ATDC Sensor.

NOTE
For details, see DIS/REASSEMBLY, ADJUSTMENT.</td></tr>
<tr><td>F12</td><td><TEST PATTERN>
This test outputs a test pattern. (From the Keypad, enter the number that corresponds to the desired test pattern.)
<table>
<tr><th>Display</th><th>Type</th><th>Display</th><th>Type</th></tr>
<tr><td>0</td><td>Halftone</td><td>3</td><td>Solid Halftone</td></tr>
<tr><td>1</td><td>1 dot Black Line</td><td>4</td><td>Halftone Line</td></tr>
<tr><td>2</td><td>2 dot White Line</td><td>5</td><td>Solid Halftone Line</td></tr>
</table>
NOTE
Paper is fed for this test from the paper source selected before F12 was invoked.</td></tr>
</table>