(3) Change Fixed Zoom

- This function allows the Tech. Rep. to change the fixed zoom ratios over the range between ×0.500 and ×2.000 according to the needs of the user.

<Setting Procedure>
1. Select the particular fixed zoom ratio to be changed.
2. Enter the desired zoom ratio from the Keypad.
3. Press the Start key to validate the new zoom ratio.

(4) PM Counters

- This function shows the counts of the PM Counter and Ports/Options Counter.

Counting system:
- PM Counter: Count-down type
- Ports/Options Counter: Count-up type

<Setting Procedure>
- Each press of the Paper Select key changes the contents of the display in the following order.

Order	Description	Order	Description
1	MAINTENANCE	5	3rd DRAWER
2	MANUAL FEED	6	4th DRAWER
3	1st DRAWER	7	ADF
4	2nd DRAWER		

<Setting a PM Counter Count>
1. Show the count of the PM Counter and press the Clear key to clear it.
2. Enter the desired count from the Keypad.
3. Press the Start key to validate the new count setting.

<Clearing a Count>
1. Show the count of the counter to be cleared.
2. Press the Clear key to clear the count. If a count is mistakenly cleared, press the Stop key to undo the clearing command.

NOTE

The copier gives the M1 display when the PM Counter reaches the setting count, if Maintenance Call is set to "1."
