5 ADJUST MODE

- The Adjust mode is used for adjustments made at the factory.

5-1. Functions Available in the Adjust Mode

Function No.	Name
1	REGISTRATION (FD)
2	IR/REGISTRATION (CD)
3	IR/REGISTRATION (FD)
4	IR/ZOOM (CD) <COPY>

Function No.	Name
6	IR/ZOOM (FD) <COPY>
8	ATDC SENSOR (MANUAL)
9	IR/SHADING POSITION

5-2. Entering the Adjust Mode

<Procedure>

1. Show the Tech. Rep. Mode menu screen.
2. Perform the following steps to set the copier into the Adjust mode.

   Press the Stop key. ➡ Press the Start key.

3. From the Keypad, enter the number that corresponds to the particular adjust mode function to be used.
4. Press the Start key. This shows the currently set data value.
5. From the Keypad, enter the desired data value.
6. Press the Start key to validate the new data value entered.

<Leaving the Adjust Mode>

- Press the Panel Reset key.