5-3. Settings in the Adjust Mode

Tech. Rep. Mode ▶ Adjust

<table>
<tr><th>Adjust Function No.</th><th>Setting (The default is Highlighted).</th></tr>
<tr><td>1</td><td><REGISTRATION (FD)>
Adjusts registration in the sub-scanning direction on the engine side.
<table><tr><td>Data</td><td>74 ..... 100 ..... 126</td></tr><tr><td>Description</td><td>Approx. -6mm..... 0mm .....Approx. +6mm</td></tr></table>Variable in approx. 0.23-mm increments.</td></tr>
<tr><td>2</td><td><IR/REGISTRATION (CD)>
Adjusts registration in the main scanning direction on the IR side.
<table><tr><td>Data</td><td>36 ..... 100 ..... 164</td></tr><tr><td>Description</td><td>Approx. -5.4mm..... 0mm .....Approx. +5.4mm</td></tr></table>Variable in approx. 0.08-mm increments.</td></tr>
<tr><td>3</td><td><IR/REGISTRATION (FD)>
Adjusts registration in the sub-scanning direction on the IR side.
<table><tr><td>Data</td><td>84 ..... 100 ..... 116</td></tr><tr><td>Description</td><td>Approx. -2mm..... 0mm .....Approx. +2mm</td></tr></table>Variable in approx. 0.13-mm increments.</td></tr>
<tr><td>4</td><td><IR/ZOOM (CD) COPY>
Adjusts the zoom ratio in the main scanning direction on the IR side (during a copy cycle).
<table><tr><td>Data</td><td>90 ..... 100 ..... 110</td></tr><tr><td>Description</td><td>×0.990 ..... ×1.000 ..... ×1.010</td></tr></table></td></tr>
<tr><td>6</td><td><IR/ZOOM (FD) COPY>
Adjusts the zoom ratio in the sub-scanning direction on the IR side (during a copy cycle).
<table><tr><td>Data</td><td>90 ..... 100 ..... 110</td></tr><tr><td>Description</td><td>×0.990 ..... ×1.000 ..... ×1.010</td></tr></table></td></tr>
</table>