<table>
<tr><th>Adjust Function No.</th><th>Setting (The default is Highlighted).</th></tr>
<tr><td>8</td><td><ATDC SENSOR (MANUAL)>
Makes a manual adjustment of ATDC Sensor gain.
<table><tr><td>Data</td><td>80 ..... 129 ..... 170</td></tr><tr><td>Description</td><td>Darker .... Lighter</td></tr></table></td></tr>
<tr><td>9</td><td><IR/SHADING POSITION>
Corrects the IR shading position.
<table><tr><td>Data</td><td>60 ..... 100 ..... 140</td></tr><tr><td>Description</td><td>Approx. -5mm..... 0 .....Approx. +5mm</td></tr></table>Variable in approx. 0.13-mm increments.</td></tr>
</table>