CONTENTS

1 SERVICE INSTRUCTIONS

1-1. Precautions for Disassembly/Adjustments..... D-1
1-2. Instructions for Handring the PWBs with MOS ICs..... D-2
1-3. Handring of the PC Drum D-2
1-4. Parts which must not be Touched..... D-4

2 DISASSEMBLY/REASSEMBLY

2-1. Doors, Covers, and Exterior Parts Identification and Removal Procedures D-5
2-2. Removal of PWBs D-7
2-3. Paper Take-Up/Transport Sections D-9
(1) Removal of the Upper Paper Take-Up Unit D-9
(2) Removal of the Lower Paper Take-Up Unit D-11
(3) Removal of the Paper Take-Up Rolls D-12
(4) Cleaning of the Paper Take-Up Rolls D-12
(5) Cleaning of the Synchronizing Rollers D-12
(6) Replacement/Cleaning of Paper Dust Remover..... D-12
(7) Removal of the Suction Unit..... D-13
(8) Disassembly of the Suction Unit D-14
(9) Disassembly of the Multi Bypass Unit..... D-15
• Cleaning of the Paper Take-Up Roll D-18
• Cleaning of the Feed Roll..... D-18
• Cleaning of the Paper Separator Roll D-18
2-4. Optical Section..... D-19
(1) Cleaning of the Original Glass..... D-19
(2) Cleaning of the Scanner Shaft..... D-19
(3) Cleaning of the Scanner Rail..... D-19
(4) Removal of the Scanner..... D-20
(5) Cleaning of the Exposure Lamp..... D-20
(6) Removal of the Thermal Fuse D-21
(7) Cleaning of the 1st/2nd/3rd Mirrors..... D-21
(8) Cleaning of the Lens and 4th/5th Mirrors D-22
(9) Winding of the Lens Drive Cable..... D-23
(10) Winding of the Scanner Drive Cable..... D-24
(11) Cleaning of the 6th Mirror Protection Filter..... D-25
(12) Cleaning of the Cooling Fan Filter..... D-25
2-5. PC Unit..... D-26
(1) Removal of the PC Unit D-26
(2) Disassembly of the PC Unit..... D-26