CONTENTS

(3) Replacement of the PC Drum D-31
(4) Replacement/Cleaning of the Toner Scattering Prevention Plate D-31
(5) Cleaning of the Ds Positioning Collars D-31
(6) Cleaning of Toner Antispill Trap D-31
(7) Replacement of the Cleaning Blade D-32
(8) Replacement of the Starter D-32
(9) Cleaning of the AIDC Sensor D-33
(10) Cleaning of the PC Drum Paper Separator Fingers D-33
(11) Replacement/Cleaning of the Toner Antispill Seal D-33
(12) Cleaning of the Toner Antispill Plate D-34
(13) Cleaning of the Main Erase Lamp Filter D-34
(14) Cleaning of the Image Erase Lamp D-34
(15) Replacement of the Ozone Filter D-35
(16) Replacement of the Toner Collecting Box D-35
2-6. PC Drum Charge Corona/Image Transfer Corona Unit D-36
(1) Cleaning/Replacement of the Drum Charge Corona Wire D-36
(2) Cleaning of the PC Drum Charge Corona Grid Mesh D-37
(3) Cleaning of the PC Drum Charge Corona Housing D-37
(4) Cleaning/Replacement of the Image Transfer Corona Wire D-37
(5) Cleaning/Replacement of the Paper Separator Corona Wire D-38
(6) Cleaning of the Image Transfer/Paper Separator Corona Housing D-39
(7) Cleaning of the Image Transfer Guide Plate D-39
2-7. Fusing Unit D-40
(1) Removal of the Fusing Unit D-40
(2) Disassembly of the Fusing Unit D-40
(3) Replacement/Cleaning of the Upper Paper Separator Fingers D-43
(4) Cleaning of the Lower Paper Separator Fingers D-44
(5) Cleaning of the Lower Guide Plate D-44
(6) Cleaning of the Thermistors D-44
(7) Cleaning of the Thermal Switch D-44
(8) Replacement/Cleaning of the Cleaning Roller D-45
(9) Replacement/Cleaning of the Upper Fusing Roller D-45
(10) Replacement/Cleaning of the Lower Fusing Roller D-45
(11) Removal of the Exit/Duplex Switching Unit D-46