No.	Part Name	Removal Procedure
1	Front Door	Open the Front Door; remove two Front Door Hinge Shafts; remove the Belt Mounting screw inside the Front Door.
2	Control Panel	Open the Front Door; remove the Right Door; remove the Upper Left Cover; remove four screws that secure the Control Panel.
3	Original Width Scale	Remove two screws that secure the Scale.
4	Original Glass	
5	Rear Upper Cover (small)	Remove the Original Cover; remove one screw that secures the Rear Upper Cover (small).
6	Left Hinge Cover	Remove the Original Cover and then one screw that secures the Left Hinge Cover.
7	Rear Upper Cover	Remove the Original Cover; remove the Right and Left Hinge Covers; remove the Rear Upper Cover (small); remove the Right Cover; remove one screw that secures the Rear Upper Cover.
8	Right Hinge Cover	Remove the Original Cover; remove one screw that secures the Right Hinge Cover.
9	Right Cover	Remove the Right Door and then four screws that secure the Right Cover.
10	Right Door	Open the Right Door; remove the harness from the wiring saddle; unplug three connectors; remove two screws that secure the Right Door.
11	Counter Cover	Remove the Counter Cover by snapping it off.
12	2nd Drawer	Slide out the 2nd Drawer and remove one screw that secures the Stopper at the rear left corner.
13	1st Drawer	Slide out the 1st Drawer and remove one screw that secures the Stopper at the rear left corner.
14	Original Cover	Remove the Original Cover by pulling it up.
15	Upper Left Cover	Remove six screws that secure the Upper Left Cover.
16	Left Door	Remove the Upper Left Cover; open the Left Door; unplug two connectors; remove the E-ring from the Rear Hinge Shaft; remove two screws that secure the Front Hinge Shaft Mounting Plate; remove one screw that secures the belt inside the Right Door.
17	Middle Left Cover	Remove the Upper Left Cover and then four screws that secure the Middle Left Cover.
18	Rear Cover	Remove six screws that secure the Rear Cover.