| Symbol | Name | Removal Procedure |
|---|---|---|
| PWB-A | Master Board | Remove the Rear Cover. |
| PWB-B | MSC Board | Open the Front Door. Remove the B Board Protection Cover. |
| PWB-C | Power Supply Board | Remove the Rear Cover and then the Master Board. |
| PWB-D | Noise Filter Board | Remove the Rear Cover, Master Board, Power Supply Unit Cover and then DC Supply Unit Cover. |
| PWB-H | AE Sensor Board | Remove the Original Width Scale and then the Original Glass. |
| PWB-I | Tech. Rep. Setting Switch Board | Open the Front Door. Remove the B Board Protection Cover. |
| PWB-J | SCP Board | Remove the Rear Cover. |
| PWB-R | RAM Board | Remove the Rear Cover. |
| UN1 | Control Panel | Open the Front Door. |
| UN2 | Original Size Detecting Board | Remove the Rear Cover. |
| UN3 | AIDC Sensor | Open the Front Door. Remove the PC Unit, Charge Corona Unit, PC Drum and then the Paper Separator Guide Unit. |
| UN4 | ATDC Sensor | Open the Front Door. Remove the PC Unit. |
| PU1 | DC Power Supply Unit | Remove the Rear Cover, Master Board and then the Power Supply Unit Cover. |
| PU2 | Power Supply Unit | Remove the Rear Cover, Master Board and then the ADF Connector Unit. |
| HV1 | High Voltage Unit | Remove the Rear Cover, SCP Board Mounting Plate and then the High Voltage Unit Cover. |