10	Access Mode Key (ID Key)	Permits the copier to enter or leave the Administrator mode. The key becomes valid only when "Copy Track" of the Administrator function of the User's Choice has been set to "YES."
11	Energy Saver Key	Sets the copier into the Energy Saver mode.
12	Interrupt Key	Interrupts a current job with a different one. A second press returns the copier to the previous job.
13	Clear Key	* Clears the number of copies selected. * Clears the counter counts. * Ejects a document, that has previously been fed from the Duplexing/Automatic Document Feeder onto the Original Glass, out onto the Document Exit Tray.
14	Panel Reset Key	* Initializes the copier. * Ejects a document, that has previously been fed from the Duplexing/Automatic Document Feeder onto the Original Glass, out onto the Document Exit Tray. * Allows the copier's to feed 1-sided copies from the Duplex Unit out onto the Exit Tray.
15	Stop Key	* Stops a multi-copy cycle. * Stops a Test Mode operation. * Sets the copier into the Tech. Rep. or Adjust mode.
16	Start Key	* Starts a copy cycle. * Starts a Test Mode operation. * Sets the copier into the Adjust mode.
17	Paper Select Key	Selects the paper size.
18	Auto Paper Mode Key	Selects the Auto Paper mode.
19	Enlargement Key	Selects a fixed enlargement ratio.
20	Full Size Key	Selects full size (100%).
21	Reduction Key	Selects a fixed reduction ratio.
22	Zoom Up/Down Key	Makes the zoom ratio larger or smaller in 0.1% increments, in the range between 50% and 200%.
23	Message Display	Serves as the basic source of information showing such information as warning messages and copying mode currently selected for use.