7-3. Drum Dehumidifying Heater

- Drum Dehumidifying Heater H3 is located under the Lower Synchronizing Roller. It is a panel heater that prevents condensation from forming on the surface of the PC Drum.

- H3 operates when:
  - The power cord is plugged into the wall outlet.
  - Power Switch S1 is in the OFF position.
  - Drum Dehumidifying Switch S3 is in the ON position.



