24 MEMORY BACKUP

IC1 (RAM) of RAM Board PWB-R connected to Master Board PWB-A stores the setting/adjustment values set in the Tech. Rep. modes as well as the counter counts. Backup Battery BAT1 is mounted on PWB-R to prevent the contents of memory from being lost when the power cord is unplugged or PWB-R removed from the copier. BAT1 requires a voltage of 2 V or more to retain the contents of memory.

Important

As noted above, the RAM stores critical data. If PWB-R has been replaced with a new one, memory must first be cleared and then all settings be made again. It should also be noted that PWB-R should not be replaced at the same time when PWB-A is replaced.

