PREFACE 前書き

1. The part numbers listed in Parts Manual 2 are those which were assigned to the parts making up the machine at the time the machine was originally introduced onto the market. The part numbers listed in all revised Parts Manuals from 3 and onward are only the most up-to-date part numbers of those parts which have been newly added, those old and new parts which are non-interchangeable and those parts which are interchangeable. Also included are the numbers of those parts the use of which has been discontinued.

2. Parts whose numbers are preceded by an asterisk in the Index Column on the List Page are parts to be used in only certain market areas. Therefore, please check the number in the Area column on the List Page and then compare it with the numbers given in the Area Chart on Page Ⅱ to find out which part number is applicable to your own area.
   NOTE: Parts for only certain Market Areas: The part numbers for these parts vary according to market area. In other cases, these parts are used in only restricted areas.

3. The Index Number on the List Page is composed of two numbers and two letters. Generally, only A is used as the first letter of the two letters. However, sometimes B, C, D, etc. are used when one part in the illustration, such as an electrical part or a part which varies according to market area, has two or more part numbers. The second letter of the two letters represents the modification history of that part.

4. The Area Number is listed in the Area Column for only those parts used in certain market areas. This Area Number represents the area listed opposite to it in the Chart given on Page Ⅱ. Parts having no Area Number listed in the Area Column can be used in all market areas.

5. In Parts Manual 2, the Remarks Column has been left blank. In all revised Parts Manuals from 3 and onward, the machine numbers of those machines in which the part is non-interchangeable are listed. A dash before such machine numbers means that all machines having serial numbers up to and including the number listed are included. A dash after such machine numbers means that all machines having serial numbers from that number and onward are included.

6. In the exploded views in this parts manual, parts (Screws & Washers, etc.) which are indicated with a "four-digit" number are listed in numerical order in the section "SCREWS AND WASHERS". Please check these "four-digit" numbers with the part numbers ("ten-digit" number) which should be used for ordering the parts.

7. All parts numbers consist of "ten digits" which should all be quoted when ordering a part. The price of parts can be obtained by referring to the "Parts Price List" which is separately issued.

1．パーツマニュアルNo.2には、販売当初の機械を構成している部品が記載されています。No.3以降の改訂版には、廃止された部品、新設された部品、互換性のない旧、新部品、そして互換性のある部品は最新の部品だけが記載されます。

2．リスト部の表示番号に※印がある部品は仕向部品ですので、地域No.をⅡページの地域No.対比表で照合して、国内の部品番号を使用してください。
注）仕向部品……地域により部品番号が異なる、または、一部地域にだけ使用されている部品。

3．リスト部の表示番号は、部品図の番号をあらわす2桁の数字と2桁の補助記号より構成されています。
補助記号の1桁目は、一般にはAだけですが、仕向部品、電気部品のように1つの部品図で複数の部品番号をあらわしている場合にA．B．C．…となっています。補助記号の2桁目は部品の変更経歴をあらわしています。

4．リスト部の地域No.は仕向部品にだけ記載されており、Ⅱページでその部品の使用されている地域をあらわしています。地域No.のないものは全地域使用部品です。

5．パーツマニュアルNo.2では、リスト部の備考欄は空欄になっています。No.3以降の改訂版では互換性のない部品がある場合に対象機械番号が記載されます。
機械番号の前に－記号がある場合は、その番号以前の機械が対象、後に－記号がある場合には、その番号以降の機械が対象です。

6．ネジ・ワッシャー類は、数字4桁の表示番号を使用しています。ネジ・ワッシャー部で照合の上、10桁の部品番号を使用してください。

7．部品番号は10桁で構成されています．注文は必ず10桁の部品番号を使用してください。

8．このパーツマニュアルの内容は予告なく変更されることがあります