CONTENTS

1 PRECAUTIONS FOR HANDLING THE PWBs

1-1. Precautions for Transportation and Storage S-1
1-2. Precautions for Replacement/Inspection S-1

2 FUNCTION OF SWITCHES AND VARIABLE RESISTORS ON PWBs

2-1. Master Board (PWB-A) S-2
2-2. Power Supply Board (PWB-C) S-3
2-3. Original Size Detecting Board (UN2) S-3
2-4. Tech. Rep. Settings Switches Board (PWB-I) S-4

3 TECH. REP. MODE

3-1. Tech. Rep. Mode Setting Procedure S-6
3-2. Function Mode S-9
3-3. Tech. Rep. Choice Mode S-12
3-4. Paper Size Input Mode S-19
3-5. System Setting Mode S-21
A. Changing the fixed zoom ratio S-21
B. Setting the Plug-In Counter/D-102 ..... S-22
C. Setting the marketing area S-23
3-6. Counter Mode S-24
A. Paper Counter S-25
B. Jam Counter S-26
C. Feed Retry Counter S-27
D. Trouble Counter S-28
E. Maintenance Counter S-31
F. Port/Option Counter S-32
G. Consumables Counter S-33
H. Auto CPU Reset Counter S-34
3-7. ROM Version Mode S-35
3-8. ADF Setting Mode S-36
3-9. Security Mode S-38
3-10. I/O Check S-39
3-11. Level History S-49