Description of Tech. Rep. Choice Modes

Code	Choice Mode Name	Description
SCH-00	Plug-In Counter Mode	Allows the counting mode (number of sheets or number of copy cycles) to be set for use of the Plug-In Counter.
SCH-01	Paper Size Counter Mode	Allows the counting mode to be set on a paper size basis.
SCH-02	Total Counter Mode	Allows the counting mode to be set on a paper size/copy mode basis.
SCH-04	Maintenance Call Reminder ON/OFF Mode	Allows the ON/OFF setting of the maintenance call reminder message shown on the Message Display.
SCH-05	Copy Kit Counter Mode	Allows the YES/NO setting of the Copy Kit Counter counting, and the setting of copying enable/disable at the end of counting.
SCH-15	Toner Empty Stop Mode	Allows the setting of copying enable/disable on detection of a toner-empty condition. * When copying disable is set, the copier inhibits the initiation of a new copy cycle when the toner-to-carrier ratio becomes less than about 2.5% after a toner-empty condition has been detected.
SCH-17	Automatic Paper Mode	Allows the setting of the paper size selected on a priority basis in the Automatic Paper Selection Mode.
SCH-20	Leading Edge Erase Mode	Selects whether to erase the leading edge or not.
SCH-21	Trailing Edge Erase Mode	Selects whether to erase the trailing edge or not.
SCH-23	Loop Length Adjustment Mode (Drawer Feeding)	Adjusts the length of the loop to be formed in paper before the Synchronizing Rollers.
SCH-24	Loop Length Adjustment Mode (Manual Feeding)	Adjusts the length of the loop to be formed in paper before the Synchronizing Rollers.
SCH-70	Exposure Lamp Voltage Adjustment Mode	Fine-adjusts the Exposure Lamp voltage.
SCH-90	ATDC Detection Level Mode	Selects the level at which the ATDC Sensor functions to maintain a target toner-to-carrier ratio of the developer.