7) Press the Cursor Key to change the paper size displayed on the screen in the following sequence. To define the paper size, press the OK Key or the Panel Reset Key.

Paper Size Display	Paper Size Values (mm)	
	Length (F)	Width (C)
F: C:	*Use the Multi-Copy Keys (Free setting)	
A3 ▭	420	297
A4 ▭	297	210
A4 ▯	210	297
A5 ▭	210	148
B4 ▭	364	257
B5 ▭	257	182
B5 ▯	182	257
B6 ▭	182	128
11" x 17"	432	279
11" x 14"	356	279
LEGAL	356	216
LETTER ▭	279	216
LETTER ▯	216	279
5-1/2" x 8-1/2"	216	140
FLS	330	210

8) For free setting*, enter the paper size values by the following procedure:
   a) Select the paper size display "F" *** C: ***".
   b) Press the OK Key once. (The paper size entry is enabled.)
   c) Using the Cursor Key, select "F" (length) or "C" (width).
   d) Using the Clear Key, clear the paper size.
   e) Using the Multi-Copy Keys, enter a new paper size.

Note: Free setting is mainly used when it is impossible to judge whether or not standard size paper is loaded in the Drawer. By measuring the size of that paper and entering the values, the standard size paper nearest to those values is selected and shown on the Message Display.