Screen Display	Description (Element/Cause)
C000x	Main Drive Motor malfunction
C0040/1	Suction Fan Motor malfunction
C004A/b	Original Glass Cooling Fan Motor malfunction
C004C/d	———
C0070/1	Main Hopper Toner Replenishing Motor malfunction
C0072	Sub Hopper Toner Replenishing Motor malfunction
C0200	Drum Charge Image Transfer/Paper Separator Corona malfunction
C03xx	Master Board, Harness malfunction
C04xx	Exposure Lamp malfunction
C050x	Warming-up malfunction
C051x	Abnormally low fusing temperature
C052x	Abnormally high fusing temperature
C060x	Scanner Drive Section malfunction
C061x	Lens Drive Section malfunction
C062x	Mirror Drive Section malfunction
C0650	Scanner Detecting Section malfunction
C0660	Scanner Load Section malfunction
C06Fx	Scanner Interface malfunction
C090x	3rd Drawer lift-up malfunction