Setting changing procedure

1) Using the OK Key, select the mode in which you want to change the setting.
2) Using the Clear Key, clear the current setting.
3) Using the Multi-Copy Keys, input a new setting. (See the following table.)
4) Using the OK Key or Panel Reset Key, enter the setting.

Setting	Description	
43	7 mm	Direction in which the document stop position overlaps the Original Scale
44	6 mm	
45	5 mm	
46	4 mm	
47	3 mm	
48	2 mm	
49	1 mm	
50	Initial value	
51	1 mm	Direction in which the document stop position moves away from the Original Scale
52	2 mm	
53	3 mm	
54	4 mm	
55	5 mm	
56	6 mm	
57	7 mm	
58	8 mm	