NOTE

When the RAM Board has been changed or memory cleared, the setting of each Adjust Mode must be returned to the factory setting indicated on the Factory Setting Label inside the Front Door.

Setting entry procedure

1) Press the Clear Key to clear the current setting.
2) Using the Multi-Copy Keys, input a new setting.
3) Press the OK Key or Panel Reset Key to enter the value.

Types of Adjust Modes

Code	Mode Name	Description
A-0	Lens Focal Length Adjustment	Corrects the focal length of the Lens. (For factory setting only)
A-1	Lens Full Size Position Adjustment	Adjusts the magnification ratio in the crosswise direction by finely adjusting the Lens home position.
A-2	Mirror Full Size Position Adjustment	Corrects the conjugate length of the Mirror. (For factory setting only)
A-3	Feeding Direction Magnification Ratio Adjustment	Adjusts the magnification ratio in the feeding direction by finely adjusting the scan speed.
A-4	Lens Position Full Size Registration	Registers the leading edge for full size.
A-5	Lens Position Reduction Registration	Registers the leading edge for reduction.
A-6	Book B Scan Registration	Registers the leading edge on scan B side for the Book Mode.
A-11	Lens Position Enlargement Registration	Registers the leading edge for enlargement.
A-12	Leading Edge Erase Adjustment	Corrects the width of erase on the leading edge of an image.
A-13	Trailing Edge Erase Adjustment	Corrects the width of erase on the trailing edge of an image.