* C0610

Step	Check Item	Result	Action
1	Are PJ4J and PJ3J plugged securely into PWB-J, PJ47 into M6, and PJ31 into PC90?	NO	Plug them in securely.
2	Does the voltage across PJ3J-2 on PWB-J and GND change from DC5V to DC0V when PC90 is blocked?	NO	Replace PC90.
3	Do you feel an overload when you move the Lens manually with the Power Switch OFF?	YES	Correct or replace the Cable or part being overloaded.
		NO	Replace M6 or PWB-J.

* C0620

Step	Check Item	Result	Action
1	Are PJ4J and PJ3J plugged securely into PWB-J, PJ48 into M7, and PJ32 into PC86?	NO	Plug them in securely.
2	Does the voltage across PJ3J-5 on PWB-J and GND change from DC5V to DC0V when PC86 is blocked?	NO	Replace PC86.
3	Do you feel an overload when you move the 4th/5th Mirrors manually with the Power Switch OFF?	YES	Correct or replace the part being overloaded.
		NO	Replace M7 or PWB-J.