1151SBD000BA

◆ For the Utmost safety ◆

⚠ Warning

- For replacement parts, use the genuine parts with their part numbers specified in the parts manual. Use of a wrong part could cause an overload or dielectric breakdown resulting in an electric shock or fire.
- Replace a blown fuse or thermal fuse with the corresponding genuine part with its part number specified in the parts manual. Use of a fuse with a different rating or one with the same rating but of a different type can result in a fire.
  Especially when a thermal fuse blows frequently, the thermal control system is probably faulty.
  Be sure to take necessary action.
- Before attempting to disassemble the machine, be sure to unplug its power cord. The machine contains a high voltage unit and a circuit with a large current capacity that may cause an electric shock or burn from sparking.
  The machine also contains quick moving parts, which could injure a person.
  If the machine uses a laser, a person can lose his/her eyesight by a laser beam leak.
- Wherever feasible, keep the covers and parts mounted when energizing the machine.
  If it is absolutely necessary to energize the machine with its cover removed, do not touch an exposed part that is being charged and use care not to allow your clothing to be caught by a timing belt, gear, or other moving part.
- Do not leave the machine unattended while it is being energized.

⚠ Caution

- To actuate an interlock switch with a cover removed or opened, be sure to use the interlock switch actuating jig. Use of folded paper can damage the interlock switch mechanism.