CONTENTS

1 SERVICE INSTRUCTIONS

1-1. PRECAUTIONS FOR DISASSEMBLY/ADJUSTMENTS D-1
1-2. INSTRUCTIONS FOR HANDLING THE PWBs WITH MOS ICs D-3
1-3. HANDLING OF THE PC DRUM D-3
1-4. PARTS WHICH MUST NOT BE TOUCHED D-5

2 DISASSEMBLY/REASSEMBLY

2-1. DOORS, COVERS, AND EXTERIOR PARTS: IDENTIFICATION AND REMOVAL PROCEDURES D-6
2-2. REMOVAL OF CIRCUIT BOARDS D-8
2-3. PAPER TAKE-UP/TRANSPORT SECTIONS D-10
(1) Removal of the Paper Take-Up Unit D-10
(2) Removal of the Paper Take-Up Roll/Feed Roll Assy and Separator Roll Assy D-13
(3) Cleaning of the Paper Take-Up Roll, Feed Roll, and Separator Roll D-16
(4) Cleaning of the Vertical Transport Rollers D-17
(5) Removal of the Drawers D-17
(6) Removal of the Upper Synchronizing Roller D-19
(7) Cleaning of the Upper and Lower Synchronizing Rollers D-20
(8) Replacement of the Paper Dust Remover D-20
(9) Cleaning of the Paper Dust Remover D-21
(10) Removal of the Suction Unit D-22
(11) Disassembly of the Suction Unit D-23
(12) Disassembly of the Multi Bypass Unit D-24
2-4. OPTICAL SECTION D-28
(1) Cleaning of the Original Glass D-28
(2) Cleaning of the Scanner Shaft D-28
(3) Cleaning of the Scanner Rail D-28
(4) Removal of the Scanner D-29
(5) Cleaning of the Exposure Lamp D-29
(6) Removal of the Thermal Fuse D-30
(7) Cleaning of the 1st, 2nd, and 3rd Mirrors D-30
(8) Cleaning of the Lens and 4th and 5th Mirrors D-31
(9) Winding of the Lens Drive Cable D-32
(10) Removal of Scanner Motor M2 ..... D-34
(11) Removal of the Scanner Drive Cable D-35
(12) Winding of the Scanner Drive Cable D-36
(13) Cleaning of the 6th Mirror Protective Filter D-37
(14) Cleaning of the Cooling Fan Filter D-37