CONTENTS

2-5. IMAGING UNIT D-38
(1) Removal of the Imaging Unit D-38
(2) Disassembly of the Imaging Unit D-38
(3) Replacement of the PC Drum D-42
(4) Cleaning of the Developer Scattering Prevention Plate D-42
(5) Cleaning of the Ds Positioning Collars D-42
(6) Cleaning of the Toner Antispill Trap D-42
(7) Cleaning of the Cleaning Blade D-42
(8) Replacement of the Cleaning Blade D-43
(9) Replacement of the Starter D-45
(10) Cleaning of the AIDC Sensor Board D-46
(11) Cleaning of the PC Drum Paper Separator Fingers D-46
(12) Replacement and Cleaning of the Toner Antispill Seal and Cleaning of the Toner Antispill Plate D-46
(13) Removal of Main Erase Lamp LA3 ..... D-47
(14) Cleaning of the Main Erase Lamp Filter D-47
(15) Cleaning of Image Erase Lamp LA2 ..... D-47
(16) Replacement of Image Erase Lamp LA2 ..... D-47
(17) Removal of the Ozone Filter (PC Drum Charge Corona) D-48
(18) Removal of the Ozone Filter (Image Transfer/Paper Separator Coronas) D-48
(19) Removal of the Toner Collecting Box D-48
2-6. PC DRUM CHARGE CORONA AND IMAGE TRANSFER/PAPER SEPARATOR CORONAS D-49
(1) Removal of the PC Drum Charge Corona D-49
(2) Cleaning of the PC Drum Charge Corona Housing D-49
(3) Cleaning of the PC Drum Charge Corona Grid Mesh D-50
(4) Cleaning of the Comb Electrode D-50
(5) Removal of the Image Transfer/Paper Separator Coronas D-50
(6) Cleaning and Replacement of the Image Transfer Corona Wire D-50
(7) Cleaning and Replacement of the Paper Separator Corona Wire D-51
(8) Cleaning of the Image Transfer/Paper Separator Coronas Housing D-51
(9) Cleaning of the Lower Pre-Image Transfer Guide Plate D-52
2-7. FUSING UNIT D-53
(1) Removal of the Fusing Unit D-53
(2) Disassembly of the Fusing Unit D-53
(3) Replacement and Cleaning of the Upper Fusing Paper Separator Fingers D-58
(4) Cleaning of the Lower Fusing Paper Separator Fingers D-58
(5) Cleaning of the Fusing Unit Entrance Guide Plate D-58