| No. | Part Name | Removal Procedure |
|---|---|---|
| 1 | Front Door | Swing down No. 1. → Remove two Front Door hinge shafts. Remove one belt mounting screw inside the Front Door. |
| 2 | Control Panel | Raise No. 12. → Swing down No. 1. → Open No. 8. → Remove No. 7. → Swing down No. 14. → Remove No. 13. → Remove two control panel mounting screws. → Remove two magnet attraction plate screws. → Unplug one connector from MSC Board. → Remove one connector. |
| 3 | Original Width Scale | Raise No. 12. → Remove two scale mounting screws. Note:When the Original Width Scale has been removed, use care not to lose two springs. |
| 4 | Original Glass | |
| 5 | Rear Upper Cover (Small) | Raise No. 12. → Open No. 14. → Remove No. 13. → Remove the screw cover. → Remove one Rear Upper Cover (Small) mounting screw. |
| 6 | Rear Upper Cover | Raise No. 12. → Open No. 14. → Remove No. 13. → Remove No. 5. → Open No. 8 → Remove No. 7. → Remove one Rear Upper Cover mounting screw. |
| 7 | Right Cover | Open No. 8. → Open the Multi Bypass Table. → Remove four Right Cover mounting screws. |
| 8 | Right Door (Manual Bypass Unit) | Open No. 8. → Remove two cover mounting screws. → Remove the harness from one wiring saddle. → Unplug three connectors. → Remove two Right Door mounting screws. |
| 9 | Counter Cover | Snap off the Counter Cover. (It is secured by catches at two places.) |
| 10 | 2nd Drawer | <Except 120V Areas><br>See p. D-17<br><120V Areas><br>See p. D-18 |
| 11 | 1st Drawer | |
| 12 | Original Cover | Remove No. 12 by pulling up. |
| 13 | Upper Left Cover | Swing down No. 14. → Remove six Upper Left Cover mounting screws. |
| 14 | Left Door (Exit/Duplex Switching Unit) | See p. D-61 |
| 15 | Middle Left Cover | Remove No. 13. → Remove two Middle Left Cover mounting screws. |
| 16 | Rear Cover | Remove six Rear Cover mounting screws. |