7) Blank Streaks or Bands

Cause	Step	Check Item	Result	Action
Plugged Db	1	Is Db plugged with foreign matter, caked toner, etc.?	YES	Remove foreign matter. If the problem persists, change the developer.
Drum charge failure	2	Are the Comb Electrode and grid mesh dirty?	YES	Clean or change the PC Drum Charge Corona.
	3	Is the Drum Charge Corona Wire Cleaner at the home position?	NO	Check the corona wire cleaning mechanism.
Image transfer failure	4	Is the Image Transfer Corona wire dirty?	YES	Clean or change the Image Transfer Corona.
	5	Is the Corona Wire Cleaner at the home position?	NO	Check the corona wire cleaning mechanism.
Defective PC Drum Paper Separator Fingers	6	Are the PC Drum Paper Separator Fingers dirty or deformed?	YES	Clean or replace the PC Drum Paper Separator Fingers.
Image Erase Lamp lit at abnormal timing	7	Does the Image Erase Lamp light up at abnormal timing?	YES	Check the Image Erase Lamp.
Fusing failure	8	Is the Upper Fusing Roller dirty or scratched?	YES	Clean or change the Upper Fusing Roller.
	9	Are the Upper Paper Separator Fingers dirty or scratched?	YES	Clean or change the Upper Paper Separator Fingers.