CONTENTS

1 PRECAUTIONS FOR HANDLING THE PWBs S-1
1-1. Precautions for Transportation and Storage S-1
1-2. Precautions for Replacement and Inspection S-1

2 CONTROL PANEL KEYS AND TOUCH PANEL S-2
2-1. Control Panel Keys S-2
2-2. Explanation of the Touch Panel S-3

3 FUNCTIONS OF SWITCHES AND POINTS ON PWB-I S-5
3-1. PWB-I Location S-5
3-2. Tech. Rep. Settings Switches Board PWB-I S-5

4 USER'S CHOICE MODE S-7
4-1. User's Choice Selection Screen S-7
4-2. User's Choice Function Setting Procedure S-7
4-3. User's Choice Function Tree S-8
4-4. Settings in the User's Choice S-9

5 TECH. REP. MODE S-16
5-1. Tech. Rep. Mode Menu Screen S-16
5-2. Tech. Rep. Mode Function Setting Procedure S-16
5-3. Tech. Rep. Mode Function Tree S-17
5-4. Settings in the Tech. Rep. Mode S-19
1. Function S-19
2. Tech. Rep. Choice S-20
3. System Input S-24
4. Counter S-25
5. I/O Check S-32
6. Last Trouble S-34
7. ROM Version S-34
8. RD Mode S-35
9. Accessory Test S-37
10. Level History S-39
11. Machine Status S-40
12. Admin. Mode S-40