<table>
<tr><th>Touch Panel Display</th><th>Setting (The default is Highlighted.)</th></tr>
<tr><td>Expo. Mode Priority</td><td>Specify the default exposure mode selected automatically when power is turned ON or the Panel Reset key pressed.

Auto | Manual</td></tr>
<tr><td>Expo. Level Priority</td><td>Auto: Select the default exposure level in the Auto Exposure mode.
Manual: Set the default exposure level in the Manual Exposure mode.

<Auto Exposure>
Lighter | Normal | Darker

<Manual Exposure>

Lighter | Normal | Darker

NOTE: EXP. 1 (Lighter) to EXP. 9 (Darker)</td></tr>
<tr><td>Manual Expo. Adjust</td><td>Determine the default voltage curve (EXP. level) in the Manual Exposure mode, as optimized by the type of original.

Mode 1 — Halftone images, photos
Mode 2 — Ordinary originals
Mode 3 — Originals with a colored background or faint texts

<Manual Exposure Voltages in Different Modes>
<table><tr><th colspan="10">Manual Exposure Voltage (V)</th></tr><tr><th>EXP.</th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th><th>9</th></tr><tr><td>Mode 1</td><td>+8</td><td>+5</td><td>+2</td><td>+1</td><td>0</td><td>–1</td><td>–2</td><td>–5</td><td>–8</td></tr><tr><td>Mode 2</td><td>+8</td><td>+6</td><td>+4</td><td>+2</td><td>0</td><td>–2</td><td>–4</td><td>–6</td><td>–8</td></tr><tr><td>Mode 3</td><td>+8</td><td>+7</td><td>+6</td><td>+3</td><td>0</td><td>–3</td><td>–6</td><td>–7</td><td>–8</td></tr></table>
NOTE: EXP. 5 uses as reference the voltage value automatically adjusted by the F5 operation.</td></tr>
<tr><td>Finishing Priority</td><td>Select the default finishing type when the copier is equipped with a Sorter or Staple Sorter.

Non Sort | Group
Sort | Sort Staple

+ Hole Punch

NOTE: Hole Punch can be combined with any one of the left functions.</td></tr>
</table>