[3/6]

Touch Panel Display	Setting (The default is **Highlighted**.)
Auto Panel Reset	Specify the default exposure mode selected automatically when power is turned ON or the Panel Reset key pressed. 30 sec. | **1 min.** | 2 min. 3 min. | 5 min. | No Reset
Energy Saver Mode	Set the time it takes the copier to enter the Energy Saver mode after a copy cycle has been completed or the last key operated. Use the 10-Key Pad to set the time (1 to 120 min.). 1 to 120 **(15 min.)** | OFF NOTE: The OFF setting is available for European areas only.
Drum Dehumidifier	Select whether to allow the copier to enter the Drum Dehumidifier mode automatically after it has been turned ON, or not. ON | **OFF**
Counter Removal	Select whether to reset the panel or not when the Plug-In Counter is pulled out of the copier, a magnetic card is pulled out of the Data Controller, or the Access Mode key is pressed. **ON** | OFF

[4/6]

Touch Panel Display	Setting (The default is **Highlighted**.)
Intelligent Sort	Select whether to turn "ON" or "OFF" the function that automatically switches between Sort and Non-Sort according to the number of originals loaded in the document feeder. **ON** | OFF NOTE: This function is enabled when "Mixed Orig. Detection" is turned "OFF" and the copier is in the Auto Paper or Auto Size mode.
Confirmation Beep	Select whether to turn "ON" or "OFF" the beep that sounds each time a key on the control panel is pressed or that on the Touch Panel is touched. **ON** | OFF
Original Thickness	Select whether to allow ("Thin") the user to make copies from thin originals in addition to the standard ones or not ("Standard") using the document feeder. **Standard** | Thin The orginal is pressed against the Original Width Scale when stopped. | The original is not pressed against the Original Width Scale when stopped.
Smaller Originals	Select whether to enable ("ON") a copy cycle or not ("OFF") when it is initiated by pressing the Start key with an original of the smallest detectable size (metric areas: A5 or smaller; inch areas: Letter or smaller) placed on the Original Glass. ON | OFF The copy cycle is run using the paper loaded in the default paper source. | A warning message is given and the copier inhibits the start of this copy cycle. NOTE: The default setting is OFF for the metric areas and ON for the inch areas.