<table>
<tr><th>Touch Panel Display</th><th>Setting (The default is Highlighted .)</th></tr>
<tr><td>Custom Book Copy</td><td>Make the settings for "Paper," "Zoom," "Margin," and "Erase" that are automatically recalled when Book copy is selected.
<table>
<tr><th>Function</th><th>Description</th><th>Initial Setting</th></tr>
<tr><td>Paper</td><td>Sizes of paper loaded in drawers</td><td>———</td></tr>
<tr><td>Zoom</td><td>Fixed zoom ratios</td><td>X1.000</td></tr>
<tr><td>Margin</td><td>Position: Right edge, left edge
Mode: Shift-for-Margin, Margin-by-Reduction
Width: Metric areas – 5, 10, 15, 20 mm
Inch areas – 1/4, 1/2, 3/4, 1"</td><td>No margin</td></tr>
<tr><td rowspan="2">Erase</td><td>Position: Right Edge, Left Edge, Frame, Top Edge, Center, Frame+Center
Width: Metric areas – 5, 10, 15, 20 mm
Inch areas – 1/4, 1/2, 3/4, 1"</td><td rowspan="2">No erase</td></tr>
<tr><td>Make the following selections only when Frame+Center is selected.
Frame: Metric areas – 5, 10, 15, 20 mm
Inch areas – 1/4, 1/2, 3/4, 1"
Center: Metric areas – 5, 10, 15, 20 mm
Inch areas – 1/4, 1/2, 3/4, 1"</td></tr>
</table>
NOTE: The erase width for the Top Edge and for the CD direction of the Frame is only 10mm for the metric areas and 1/2" for the inch areas.</td></tr>
<tr><td>Special Paper</td><td>Set up a drawer for special paper loading.
<table>
<tr><td>Normal</td><td>Insert Sheet</td></tr>
<tr><td>Recycled</td><td>Not for 2-Sided</td></tr>
</table>
Initial setting: Normal (for all drawers)
<table>
<tr><th>Type of Paper</th><th>Auto Paper</th><th>Automatic Drawer Switching (only of paper of the same type)</th></tr>
<tr><td>Normal</td><td>○</td><td>○</td></tr>
<tr><td>Recycled</td><td>○ NOTE 1</td><td>○</td></tr>
<tr><td>Insert Sheet</td><td>—</td><td>—</td></tr>
<tr><td>Not for 2-Sided</td><td>○ NOTE 2</td><td>○ NOTE 2</td></tr>
</table>
○: Enabled —: Disabled

NOTE 1: A warning display is given and the copy cycle is started by pressing of the Start key.
NOTE 2: Enabled only in the 1-sided copying mode.</td></tr>
</table>