4. Counter

- This function shows the counts of the various counters, thus aiding the Tech. Rep. in performing service jobs.

<Setting Procedure>
1. Select "Counter".
2. Select the desired counter function.
3. Clear or set the count according to the instructions given on the screen.

<Clearing All Counts of a Counter Type at Once>
1. Touch the "Counter Reset" key.
2. Select the type of counter to be cleared all at once.
3. Touch "Enter". This clears all counts of the counter selected.

Tech. Rep. Mode ▶ Counter

<table>
<tr><th>Touch Panel Display</th><th>Operation</th></tr>
<tr><td>Paper</td><td>Shows the number of copies made on each paper size or type (S0: standard paper; S1: recycled paper; S2: special paper; S3: disabling 2-sided copying).

<Paper 1/2>
<table><tr><th colspan="2">Paper Size</th></tr><tr><td>A3</td><td>11 X 17</td></tr><tr><td>B4</td><td>11 X 14</td></tr><tr><td>A4</td><td>Legal</td></tr><tr><td>B5</td><td>Letter</td></tr><tr><td>A5</td><td>5½X8½</td></tr><tr><td></td><td>FLS</td></tr></table>
<Paper 2/2>
<table><tr><th>Paper Type</th></tr><tr><td>S0</td></tr><tr><td>S1</td></tr><tr><td>S2</td></tr><tr><td>S3</td></tr></table>
Note: For a paper size that can be loaded both lengthwise and crosswise, the count represents the sum of both. (Ex.: A4 lengthwise/crosswise)

<Clearing a Count>
Using the ▼ or ▲ key, highlight the count to be cleared, then press the Clear key.
Note: If a count is accidentally cleared, pressing the Interrupt key will undo the clear operation.</td></tr>
</table>