<table>
<tr><th>Touch Panel Display</th><th>Operation</th></tr>
<tr><td>Jam</td><td>
<Jam Counter 3/3>
<table>
<tr><th>Display</th><th>Description</th><th>Display</th><th>Description</th></tr>
<tr><td>ADF Transport</td><td>No. of misfeeds that occurred at the transport section of the ADF</td><td>SADF Feed</td><td>No. of misfeeds that occurred at the SADF</td></tr>
<tr><td>ADF Reverse</td><td>No. of misfeeds that occurred at the turnover section of the ADF</td><td>LCT</td><td>No. of misfeeds that occurred at the LCT</td></tr>
<tr><td>ADF Exit</td><td>No. of misfeeds that occurred at the exit section of the ADF</td><td>Stack</td><td>No. of misfeeds that occurred at the sorter stacking</td></tr>
</table>
<Clearing a Count>
Using the ▼ or ▲ key, highlight the count to be cleared, then press the Clear key.
Note: If a count is accidentally cleared, pressing the Interrupt key will undo the clear operation.
</td></tr>
<tr><td>Retry</td><td>
Shows the number of paper take-up retries carried out at different paper sources.
<table>
<tr><th>Display</th><th>Description</th><th>Display</th><th>Description</th></tr>
<tr><td>1st Drawer</td><td>No. of paper take-up retries at the 1st Drawer of the copier</td><td>5th Drawer</td><td>No. of paper take-up retries at the 5th Drawer of the copier</td></tr>
<tr><td>2nd Drawer</td><td>No. of paper take-up retries at the 2nd Drawer of the copier</td><td>Dup</td><td>No. of paper take-up retries at the Duplex Unit</td></tr>
<tr><td>3rd Drawer</td><td>No. of paper take-up retries at the 3rd Drawer of the copier</td><td>Manual Feed</td><td>No. of paper take-up retries at the Multi Bypass Tray</td></tr>
<tr><td>4th Drawer</td><td>No. of paper take-up retries at the 4th Drawer of the copier</td><td>LCT</td><td>No. of paper take-up retries at the LCT</td></tr>
</table>
<Clearing a Count>
Using the ▼ or ▲ key, highlight the count to be cleared, then press the Clear key.
Note: If a count is accidentally cleared, pressing the Interrupt key will undo the clear operation.
</td></tr>
<tr><td>Trouble</td><td>
Shows the number of malfunctions that have occurred in different parts of the copier system.
<Trouble Counter 1/6>
<table>
<tr><th>Malfunction Code</th><th>Location</th><th>Malfunction Code</th><th>Location</th></tr>
<tr><td>C000X
C0040
C0046/7
C004A/b</td><td>Main Drive Motor
Suction Fan Motor
Fusing Cooling Fan
Optical Cooling Fan</td><td>C004C/d
C0070/1
C0072
C0200</td><td>Ventilation Fan
Main Hopper Motor
Sub Hopper Motor
PC Charge Corona</td></tr>
</table>
</td></tr>
</table>