Touch Panel Display	Operation
Trouble	

<Trouble 2/6>

Malfunction Code	Location	Malfunction Code	Location
C03XX	Control Board/Harness	C0520	Fuser High Temp.
C04XX	Exposure Lamp	C0600	Scanner Drive Syst.
C050X	Fuser Warm-Up	C0610	Lens Drive System
C0510	Fuser Low Temp.	C0620	Mirror Drive System

<Trouble 3/6>

Malfunction Code	Location	Malfunction Code	Location
C06FX	Scanner Interface	C092X	1st Drawer
C07XX	ADF	C095X	4th Drawer
C090X	3rd Drawer	C0990 - 6	LCC Main-Tray
C091X	2nd Drawer	C0998 - F	LCC Shift-Tray

<Trouble 4/6>

Malfunction Code	Location	Malfunction Code	Location
C09CX	LCT	C0F10	EE Sensor
C0E0X	Main Erase Lamp	C0F2X	AIDC Sensor
C0E20	Auxil. Erase Lamp	C0F3X	ATDC Sensor
C0F02	Orig. Size Det. CPU	C0F79	Paper Empty Sensor

<Trouble 5/6>

Malfunction Code	Location	Malfunction Code	Location
C0FE/FX	Original Sensor	C0b2X	Sorter (Staple Unit)
C0b0X	Sorter (Transport)	C0b3X	Sorter (Guide)
C0b10 - 3	Sorter (Paper Clamp)	C0b4X	Sorter (Gate Motor)
C0b18 - d	Original Guide Motor	C0b5X	Sorter (Stapler)

<Trouble 6/6>

Malfunction Code	Location	Malfunction Code	Location
C0b6X	Sorter (Bin Shift)	C0d20	Dup Storage
C0b7X	Sorter (Punch)	C0d5X	Dup Drive Motor
C0d00	Front/Rear Guide		

<Clearing a Count>
Using the ▼ or ▲ key, highlight the count to be cleared, then press the Clear key.
Note: If a count is accidentally cleared, pressing the Interrupt key will undo the clear operation.