<table>
<tr><th>Touch Panel Display</th><th>Operation</th></tr>
<tr><td>Port/option</td><td>
<Port/Option 3/3>
<table>
<tr><th>Display</th><th>Description</th></tr>
<tr><td>PC Drum</td><td>No. of revolutions of the PC Drum, as converted to the number of sheets of A4 crosswise paper fed through the copier</td></tr>
<tr><td>Developer</td><td>No. of sheets of paper fed through</td></tr>
<tr><td>Fusing Roller</td><td>No. of revolutions of the Fusing Roller, as converted to the number of sheets of A4 crosswise paper fed through the copier</td></tr>
<tr><td>LCT</td><td>No. of sheets of paper fed through the LCT</td></tr>
</table>
<Clearing a Count><br>
Using the ▼ or ▲ key, highlight the count to be cleared, then press the Clear key.<br>
Note: If a count is accidentally cleared, pressing the Interrupt key will undo the clear operation.
</td></tr>
</table>