6. Last Trouble

Tech. Rep. Mode ▶ Last Trouble

Touch Panel Display	Operation
Last Trouble	Touching the Last Trouble key shows the various copying settings made when the last malfunction occurred, thereby providing a basis for determining the cause of the problem.

Item	Description
No. of copies	No. of copies setting
Copy paper	Auto Paper, paper size
Zoom ratio	Auto Size, zoom ratio
Image density	Auto Exposure, Manual Exp. setting
Mixed Orig. Detection	On, off
Orig. ▶ copy	1 ▶ 1, 1 ▶ 2, 2 ▶ 2, etc.
Finishing	Non-Sort, Sort, Group, Sort Staple, Punch
Cover	Cover (Front), Cover (Front & Back), Copied Cover, Non-Copied Cover
Page Insertion	Copied Inserts, Non-Copied Inserts
OHP Interleaving	Copied Interleaves, Non-Copied Interleaves
File Margin	Method, position, width
Erase	Method, position, width

7. ROM Version

Tech. Rep. Mode ▶ ROM Version

Touch Panel Display	Operation
ROM Version	Shows the ROM versions of the following boards.

Display		Description
MSC/Panel	IC2B	PWB-B
Master	IC2A	PWB-A
SCP	IC1F	PWB-F
ADF		PWB-A of AFR-13, AF-5
Sorter		PWB-A of S-208, ST-211, S-106, ST-104
Data Controller	IC2	D-102 board