8. RD Mode

Tech. Rep. Mode ▶ RD Mode

| Touch Panel Display | Setting (The default is **Highlighted**.) |
|---|---|
| RD Mode | Make the initial settings of the copier for the Data Terminal. |
| ID Code | The entry of a 7-digit ID code from the 10-Key Pad enables making the following settings. When the ID code is entered and transmitted after the initial settings have been made, it executes the transmission of MAINT. START to the Center. |
| Maintenance | Used to make the initial settings and various transmissions. |
| DT Setting | Enter the following data. |
| CT-ID | Enter the 4-digit ID number of the Center which has been programmed in the Center personal computer. |
| DT-ID | Enter the 6-digit ID number of the Data Terminal. |
| TEL No. | Enter the 19-or-less-digit phone number of the modem connected to the Center personal computer.<br>Note 1: When the office extension and outside line use different systems, enter "P" for a "pulse" telephone line or "T" for a "tone" telephone line before the outside line number.<br>Note 2: The time it takes the private branch exchange (PBX) system to switch from the extension line to the outside line varies depending on the type of PBX system used. Set this time as follows.<br>Fixed switching time: Enter the pause code "–" (a single "–"lasts 2 sec.).<br>Varying switching time: Enter the wait code "W." |
| Common DT | |
| Dial Mode | Select the type of telephone line of the user.<br>Pulse line / Tone line<br>**Pulse** / Tone |
| Auto Receive | Choose "Yes" or "No" for the auto reception function.<br>YES / **NO**<br>Note: Select "Yes" if the line is dedicated to the Data Terminal. |
| Result Code | Set the value according to the type of modem on the copier.<br>Note: Don't use this function as long as "5" has been set for it. |
| Report Format | Japan only<br>**10 BIT** |
| RAM Clear | Reinitializes the Data Terminal.<br>Maintenance / **NO** |