Touch Panel Display	Setting
RD Mode	.....
Maintenance	.....
Data Save/Load	Enables transmission of Data Save and Data Load.
Data Save	Transmits the command that saves the PPC RAM data to the Center.
Data Load	Transmits the command that loads the data sent by Data Save back to the PPC.
Initial Transmission	Used to perform the initial transmission from the PPC to the Center to check for correct communication when the Data Terminal has been set up.
Call Completion	Used by the Tech. Rep. to notify the Center that his/her service job for the copier has been completed.
Counter Clear	Used to clear the count of the spare counter set by the Center. <Procedure> 1. Select the spare counter to be cleared. 2. Touch "Call Completion" which transmits a signal to the Center to clear the count of the specified counter.