11. Machine Status

- This function shows the codes of isolated malfunctions which are currently present. This screen is also accessible by touching the wrench mark shown at the bottom left corner of the Basic screen under normal operating conditions.

Tech. Rep. Mode ▶ Machine Status

<table>
<tr><th>Touch Panel Display</th><th>Setting</th></tr>
<tr><td>Machine Status</td><td>Of the malfunction codes listed below, those that have occurred are displayed, together with the functions that are disabled by these malfunctions. Up to five isolated malfunctions are shown. When a sixth isolated malfunction occurs, the copier considers it as an ordinary malfunction. Even if there are less than five isolated malfunctions, if there are isolated malfunctions occurring at all paper sources, the next isolated malfunction will be regarded as an ordinary one.
<table>
<tr><th>Malfunction Code</th><th>Description</th></tr>
<tr><td>C004d/45</td><td>Cooling Fan Motor malfunction (Ventilation/Fusing Section)</td></tr>
<tr><td>C0350 to 52</td><td>SP communication failure</td></tr>
<tr><td>C09XX</td><td>Paper take-up failure</td></tr>
<tr><td>C0dXX</td><td>Duplex Unit malfunction</td></tr>
<tr><td>C0F2X</td><td>Faulty AIDC Sensor</td></tr>
<tr><td>C0F7X</td><td>Faulty Paper Empty Sensor</td></tr>
<tr><td>C0FEX to FX</td><td>Faulty Original Size Detecting Sensor</td></tr>
<tr><td>C0b3X / 5X to 7X</td><td>Sorter malfunction</td></tr>
</table>
<Clearing Procedure>
With the Machine Status screen on the Touch Panel, swing open and close the Front Door to clear all the isolated malfunctions.</td></tr>
</table>

12. Admin. Mode

- This function is used to enter or change the administrator number, in addition to the functions set in the "Administrator Mode" available from User's Choice.

Tech. Rep. Mode ▶ Admin. Mode

<table>
<tr><th>Touch Panel Display</th><th>Setting</th></tr>
<tr><td>Copy Track</td><td rowspan="4">See "Administrator Mode" of User's Choice.</td></tr>
<tr><td>Copy Track Data</td></tr>
<tr><td>Max. Copy Sets</td></tr>
<tr><td>User Help</td></tr>
<tr><td>Administrator # Input</td><td>From the 10-Key Pad, enter a 4-digit number (0000 to 9999) that serves as an ID number for opening the "Admin. Mode" of User's Choice.</td></tr>
</table>