C0952: 4th Drawer Downward Motion Failure
C0953: 4th Drawer Upward Motion Failure
C0956: 4th Drawer Ejection Failure
18) C0990: Main Tray Upward Motion Failure T-89
C0991: Main Tray Downward Motion Failure
C0992: Main Tray Downward Motion Failure
C0993: Main Tray Upward Motion Failure
C0994: Elevator Motor M26's Failure to Turn
19) C0998: Shifter Transfer Failure T-91
C0999: Shifter Return Failure
C099A: Shifter Return Failure
C099b: Shifter Transfer Failure
C099C: Shift Motor M27's Failure to Turn
20) C099E: Shift Gate Position Detecting Failure T-93
C099F: Shift Gate Position Detecting Failure
C0996: 3rd Drawer Lock Release Failure
C0F79: Paper Empty Sensor Failure
21) C0d00: Duplex Unit Front/Rear Edge Guide Plate Home Position Detection Failure T-95
C0d20: Duplex Unit Gate Unit Home Position Detection Failure
C0d50: Duplex Unit Drive Motor M31's Failure to Turn
C0d51: Duplex Unit Drive Motor M31 Turning at Abnormal Timing
22) C0E00: Main Erase Lamp LA2's Failure to Turn ON T-97
C0E01: Main Erase Lamp LA2 Turning ON at Abnormal Timing
23) C0E20: Image Erase Lamp LA3's Failure to Turn ON T-98
24) C0F02: Original Size Detecting Board UN2 Malfunction T-99
25) C0F10: AE Sensor Board PWB-H Malfunction T-101
26) C0F20: AIDC Sensor Board PWB-G Variation Correction Failure T-102
C0F22: AIDC Sensor Board PWB-G Grid Voltage (Vg) Correction Failure
C0F23: AIDC Sensor Board PWB-G Exposure Correction Failure
27) C0F30: ATDC Sensor UN3 Failure T-103
C0F31: ATDC Sensor UN3 Failure

4-3. Power Malfunctions T-104
1) Main Relay Does Not Turn ON. T-104
2) Main Relay Turns ON But the Control Panel Gives No Display T-106

4-4. Miscellaneous T-107

5 IMAGE FAILURE

5-1. Image Failure Troubleshooting T-108