◆C0500, C0510

Step	Check Item	Result	Action
1	Does H1 light up when the Power Switch is turned ON?	NO	Go to step 5.
2	Is TH1 installed properly?	NO	Reinstall TH1.
3	Is TH1 dirty?	YES	Clean or change TH1.
4	Measure resistance of TH1. Is is infinite?	YES	Change TH1.
		NO	Change PWB-A.
5	Perform the "Controller Board Check." Is malfunction code "C0311" displayed?	YES	Change PWB-A.
6	Check H1 for continuity. Is there continuity?	YES	Change SSR1.
		NO	Change H1 or TS1.

◆C0520

Step	Check Item	Result	Action
1	Does H1 remain lit after the copier has warmed up?	NO	Go to step 4.
2	Perform the "Controller Board Check." Is malfunction code "C0311" displayed?	YES	Change PWB-A.
3	Does H1 turn OFF?	NO	Change SSR1.
4	Is TH1 installed properly?	NO	Reinstall TH1.
5	Is TH1 dirty?	YES	Clean or change TH1.
6	Measure resistance of TH1. Is is 0 Ω or close to 0?	YES	Change TH1 (TH2).
		NO	Change PWB-A.