◆C0600

Step	Check Item	Result	Action
1	Are all connectors on PWB-F plugged in securely?	NO	Plug them in securely.
2	Is the voltage across PWB-F PJ1F-2 and GND DC5V?	NO	Check the connection of the DC5V line and, if it is intact, change PU1.
3	Perform the "Controller Board Check." Is malfunction code "C031F" or "C0320" displayed?	YES	Change PWB-A.
		NO	Change PWB-F or M2.

◆C06FX

Step	Check Item	Result	Action
1	Are PWB-A PJ8A and PWB-F PJ2F connected securely?	YES	Change PWB-A or PWB-F.
		NO	Connect securely.