◆C0910

Step	Check Item	Result	Action
1	Does PC66 operate properly? Using the IC Port Data Check function, make an input port check on PWB-A (IC3A) APB2.	YES	Change PWB-A.
		NO	Check the Paper Take-Up Roll for operation. If it is operational, change PC66.

◆C0920

Step	Check Item	Result	Action
1	Does PC65 operate properly? Using the IC Port Data Check function, make an input port check on PWB-A (IC3A) APB1.	YES	Change PWB-A.
		NO	Check the Paper Take-Up Roll for operation. If it is operational, change PC65.

◆C0914

Step	Check Item	Result	Action
1	Slide out the 2nd Drawer and slide it back into the copier. Does M14 turn at this time?	YES	Go to step 4.
2	Perform the "Controller Board Check." Is malfunction code "C032E" displayed?	YES	Change PWB-A.
		NO	Replace PWB-A.
3	Does the voltage across PWB-C PJ9C-4 and GND change from DC0V to DC24V when the 2nd Drawer is slid back into the copier?	YES	Change M14.
		NO	Change PWB-C.
4	Does the voltage across PWB-A PJ23A-5 and GND vary between DC0V and DC5V while M14 is turning?	YES	Change PWB-A.
		NO	Change PC68.

◆C0924

Step	Check Item	Result	Action
1	Slide out the 1st Drawer and slide it back into the copier. Does M13 turn at this time?	YES	Go to step 4.
2	Perform the "Controller Board Check." Is malfunction code "C033O" displayed?	YES	Change PWB-A.
3	Does the voltage across PWB-C PJ9C-2 and GND change from DC0V to DC24V when the 1st Drawer is slid back into the copier?	YES	Change M13.
		NO	Change PWB-C.
4	Does the voltage across PWB-A PJ23A-7 and GND vary between DC0V and DC5V while M13 is turning?	YES	Change PWB-A.
		NO	Change PC67.