◆C0F02

| Step | Check Item | Result | Action |
|---|---|---|---|
| 1 | Are PJ62 on UN2 and PJ7A on PWB-A plugged in securely? | NO | Plug them in securely. |
| 2 | Does the voltage across PJ7A-6 on PWB-A and GND vary between DC0V and DC5V? | YES | Change PWB-A. |
| | | NO | Change UN2. |

◆C0FE1 to C0FFF

| Step | Check Item | Result | Action |
|---|---|---|---|
| 1 | Are the jumper connectors plugged correctly into J1 and J2 on UN2? | NO | Change the jumper connector positions. |
| 2 | Is each Original Size Detecting Sensor installed in correct position? | NO | Reinstall. |
| 3 | Is the malfunction code displayed again after the Original Size Detecting Sensor corresponding to the malfunction code has been changed? | YES | Change UN2 or PWB-A. |